

This is An Adaptor for the Blaster C Tracer to put it in the Novritsch Rifle Mock Suppressor.

I came up with this idea because I wanted to use a large suppressor without giving up my tracer. Since there are very few (if any) tracers available in the size of a rifle mock suppressor, I decided to build an adapter.

Adapter Installation Guide

Purpose:

This adapter allows the use of a rifle-sized mock suppressor together with a tracer unit. It is designed so the tracer can be easily inserted, removed, and switched on without difficulty.

Step 1 – Insert the Base Part

- Place the larger part of the adapter into the suppressor first.
- Ensure it is seated securely inside.

Step 2 – Install the Tracer

- Insert the tracer unit into the upper part of the adapter.
- Make sure the tracer sits firmly in position.

Step 3 – Insert the Upper Part

- Slide the upper part (with the tracer inside) into the suppressor.
- Push it in until it is fully aligned with the base part.

Step 4 – Operation

- To switch the tracer on, simply pull out the upper part of the adapter.
- After switching it on, reinsert the upper part back into the suppressor.