


NOVITSCH

ANTI-FOG UNIT

START

This is your new Novritsch Anti-Fog Unit. Treat it nicely and it will support you through the hottest games, the coldest games, and anything in between.

We know instructions are always the least exciting part of a new piece of equipment, and so we don't want to stop you from trying everything out. But if you need more in-depth information, tips, and tricks, then visit novritsch.com/academy to find anything you might need.



Control Knob - Turn to switch on, and then adjust the power of the fan up or down.

Turbo Button - Pressing this gives 30 seconds of maximum power, to clear things up fast.

Charging Port - Underneath the cover is a USB-C port for charging the unit.

BATTERY

The **Indicator LED** on the side of your unit is designed to inform you about the battery status of your unit. While charging, it will flash through a range of colours as the charge increases, until it stops on a solid green light for fully charged.

While in use, if you press the **Battery Status** button, then it will light up to show you the charge left on the battery.

0 - 20% Remaining - Red


20 - 50% Remaining - Yellow

More Than 50% - Green

INSTALLATION

Your unit comes with an installation punch tool included, which you can use to cut the correct shaped hole in your goggles. Line it up on the rubber in the middle of your goggles, and then use a hammer and a solid surface to punch through.

The simplest way to learn how to do this is to go to **novritsch.com/academy** and follow our in depth tutorials where we discuss the points you need to watch out for and guide you through the process.



DISCLAIMER

In no event shall NOVITSCH Trading GmbH be liable for any direct, indirect, punitive, incidental, special consequential damages, to property or life, whatsoever arising out of or connected with the use or misuse of its products.